



# *Fahrenheit*

**DVD-28**

## **OWNER'S MANUAL**

### **Mobile Video System**

---



**DVD/VCD/CD/MP3 PLAYER WITH  
AM/FM-STEREO DIGITAL PLL TUNING RADIO  
ANTI-THEFT FLIP DOWN DETACHABLE PANEL**

# CONTENTS

---

Safety Information .....	3
Disc Notes .....	4
Installation.....	5
Electric Connection .....	8
Remote Control... ..	9
Basic Operation .....	11
Radio operation .....	13
Disc operation.....	14
To select the first track/chapter to play .....	14
To scan disc.....	14
To play disc in random.....	14
MP3 Disc Play.....	15
On-Screen Display Function.....	15
Muti-audio Language Function.....	16
Title Menu Function (For DVD only) .....	16
Multi-subtitle Language Function (For DVD only).....	16
Multi-angle Function (For DVD only).....	16
Setup .....	17
Initial Setup.....	17
General Setup.....	17
Speaker Setup .....	19
Audio Setup .....	19
Preferences Setup .....	20
Defaults Table .....	22
Specifications .....	23
Trouble Shooting.....	24

## SAFETY INFORMATION

---

### CAUTION:

THIS DVD PLAYER IS A CLASS I LASER PRODUCT. HOWEVER THIS DVD PLAYER USES A VISIBLE/INVISIBLE LASER BEAM WHICH COULD CAUSE HAZARDOUS RADIATION EXPOSURE IF DIRECTED. BE SURE TO OPERATE THE DVD PLAYER CORRECTLY AS INSTRUCTED.

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE. DO NOT OPEN COVERS AND - DO NOT REPAIR YOURSELF. REFER SERVICING TO QUALIFIED PERSONNEL.

### WARNING:

- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, AND ANNOYING INTERFERENCE, USE ONLY THE RECOMMENDED ACCESSORIES.
- THIS DEVICE IS INTENDED FOR CONTINUOUS OPERATION.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

### Region Management Information

#### Region Management Information:

This DVD Player is designed and manufactured to respond to the Region Management Information that is recorded on a DVD disc. If the Region number described on the DVD disc does not correspond to the Region number of this DVD Player, this DVD Player cannot play this disc.

## DISC NOTES

### Disc formats supported by this player



#### DVD

12 cm disc  
(Single-sided disc only)



#### Video CD

12 cm disc



#### CD

12 cm disc



#### MP3

12 cm disc

### Discs which cannot be played with this player

- DVD-ROM
- DVD-R/DVD-RAM
- CDV
- CD-G

### Handling and Cleaning

- Dirt, dust, scratches and warping disc will cause misoperation.
- Do not place stickers or make scratches on discs.
- Do not warp discs.
- A disc should always be kept in its case when not in use to prevent from damaging.
- Do not place discs in the following places:
  1. Direct sunlight
  2. Dirty, dusty and damp areas
  3. Near car heaters
  4. On the seats or dashboard

### Disc Cleaning

Use a dry soft cloth to wipe the surface. If the disc is quite dirty, use a soft cloth slightly moistured with isopropyl (rubbing) alcohol. Never use solvents such as benzine, thinner or conventional record cleaners as they may mar the surface of the disc.

#### Note:

A disc may become somewhat scratched (although not enough to make it unusable) depending on your handle it and conditions in the usage environment. Note these scratches are not an indication of any problem with the player.

Label side up



Do not touch the underside of the disc



Do not bend




Wipe the disc from center toward the outside edge

### Preparing New Discs with Rough Spots

A new disc may have rough edges on its inside and outside edges. If a disc with rough edges is used, the proper setting will not be performed and the player will not play the disc. Therefore, remove the rough edges in advance by using a ball point pen or pencil as shown on the right. To remove the rough edges, press the side of the pen or pencil against the inside and outside edges of the disc.

Rough spots on outside edge



Rough spots on inside edge

# INSTALLATION

---

## Notes:

- Choose the mounting location where the unit will not interfere with the normal driving function of the driver.
- Before finally installing the unit, connect the wiring temporarily and make sure it is all connected up properly and the unit and the system work properly.
- Use only the parts included with the unit to ensure proper installation. The use of unauthorized parts can cause malfunctions.
- Consult with your nearest dealer if installation requires the drilling of holes or other modifications of the vehicle.
- Install the unit where it does not get in the driver's way and cannot injure the passenger if there is a sudden stop, like an emergency stop.
- If installation angle exceeds  $30^{\circ}$  from horizontal, the unit might not give its optimum performance.





- Avoid installing the unit where it would be subject to high temperature, such as from direct sunlight, or from hot air, from the heater, or where it would be subject to dust, dirt or excessive vibration.


## DIN FRONT/REAR-MOUNT

This unit can be properly installed either from "Front" (conventional DIN Front-mount) or "Rear" (DIN Rear-mount installation, utilizing threaded screw holes at the sides of the unit chassis). For details, refer to the following illustrated installation methods.

# INSTALLATION




While installing the front panel,  
please mount the left side first,  
then push the right side.




# INSTALLATION

**CAUTION:** Do not install the detachable panel before connecting the wire.


1. The unit is designed for negative terminal of the battery which is connected to the vehicle metal. Please confirm it before installation.
2. If the car interior is extremely hot, as after being parked in the sun, do not use the player until the car has been driven for a while to cool off the interior.
3. Press the OPEN button to flip down the front panel (see fig.1), then take away the front panel (see fig.2) and put it in the protective case (see fig.3) safe keeping.
4. Install the front panel back into its bracket and then push it back to the position for playing (see fig.4).




( FIG.1 )



( FIG.2 )




( FIG.3 )



( FIG.4 )


# ELECTRIC CONNECTION

## WIRING CONNECTION





# REMOTE CONTROL



1. CLK Press it to change the display to clock display.
2. MODE Press it to change between radio or disc model.
3. SETUP Display the SETUP menu.
4. OSD(BAND) Display statistical disc information during playback (To change the band in radio stations)
5. ST/MO(AUDIO) Press it to select STEREO or MONO (In disc stations, press it to changing of the AUDIO soundtrack on multi-audio soundtrack DVD disc. Changing of the sound mode of the VCD/CD disc)
6. SEL Press it to change audio mode through Volume, Bass, Balance and Fader modes.
7. TITLE/PCB(A/P) Display the TITLE menu that is stored in DVD disc changing between PBC ON and PBC OFF on the VCD disc. (Auto store and preset scan function in radio stations.)
8. VOL+/VOL- Press it to adjust volume level.
9. ▲/▼/◀/▶ Cursor buttons in MENU mode.
10. MENU/ Press it to display the root menu of the DVD disc./ Press and hold for more than 2 seconds can have subwoofer.
11. STOP Press it to stop playback.
12. PLAY/PAUSE Press once to pause a play, press again to resume playback.
13. POWER Press it to turn on the unit, press it again to turn off.
14. MUTE Press it to mute down the sound.
15. REPEAT Switch the Repeat mode of DVD/VCD/CD disc.
16. ANGLE Changing of the view angle on multi-angle DVD disc
17. EQ Press it to turn to equalization function.
18. SUBTITLE(LO/DX) Changing of the SUBTITLE language on multi-subtitle language on multi-subtitle language DVD disc. (To select LO/DX function in radio stations)
19. ⏮ / ⏭ Press ⏭ to skip to the next track & press ⏮ to skip back one track.
20. ENTER Confirm the Track/Chapter selected with the number key or selected with the cursor buttons on TV screen.
21. 0 - 9 Numeric buttons
22. +10 Press it to select 10th digits

# REMOTE CONTROL

---

## Preparing the Remote Control

### Inserting the Batteries


1. Open the battery compartment cover.
2. Insert the new batteries. Make sure that the positive and negative terminals of the batteries are oriented as indicated.
3. Close the cover

### Using the Remote Control


Face the remote control towards the player front face IR mark (remote control signal receiver).

Operation angle: About  $\pm 30$  degree in each the direction of the front of the IR mark.

**To prevent damage to the unit, be sure to follow the connection diagram (page 8).**



## BASIC OPERATION



### ON/OFF [PWR BUTTON] (15)

Press it to turn on the unit or off the unit.

### FLIP DOWN THE FACEPLATE [OPEN BUTTON] (1)

Press it to flip down the faceplate.

### SET THE CLOCK [CLK BUTTON] (3)

Press it to change the display to clock display. Press it again to return to previous display. In clock display, press and hold for about 2 seconds until the hour display flashes. Press VOL +/VOL- to adjust hours, press CLK button to flash minute then press VOL +/VOL- to adjust minutes.

### MUTE [MU BUTTON] (13)

Press it to mute down sound. Press it again to release this mode and recover previous volume level.

### SELECT MODE [MOD BUTTON] (18)

Press it repeatedly to select DISC, AUX IN (optional) and RADIO mode.

### EQUALIZATION [EQ BUTTON] (5)

Press it to turn to equalization function and to select desired audio mode. There are four kinds of mode as below:



## BASIC OPERATION


---

### **VOL +/- VOL- BUTTON (2)**

Adjust volume level

### **SELECT AUDIO MODE [SEL BUTTON] (3)**

Press it to change audio mode through volume, bass, treble, balance, and fader modes. Use VOL +/- VOL- buttons to adjust the selected mode. When mode has not been adjusted for several seconds, display returns to normal radio or CD display.



#### **Volume**

Adjust volume level by using VOL +/- VOL- buttons.

Note: The unit is initially set to volume mode.

#### **Bass**

Press SEL button one time. Adjust bass level by using VOL +/- VOL- buttons.

#### **Treble**

Press SEL button two times. Adjust treble level by using VOL +/- VOL- buttons.

#### **Balance**

Press SEL button three times. Adjust sound balance between left and right speakers by using VOL +/- VOL- buttons.

#### **Fader**

Press SEL button four times. Adjust sound balance between front and rear speakers by using VOL +/- VOL- buttons.

### **LIQUID CRYSTAL DISPLAY**

The LCD can show the current state of the unit.

### **FLASHING LED (19)**

If the front panel is not on the main unit, LED will be flashing.

### **RESET FUNCTION [RESET BUTTON] (20)**

RESET button is placed on the housing and must be activated with either a ballpoint pen or thin metal object. The RESET button is to be activated for the following reasons:

- Initial installation of the unit when all wiring is completed.

- All the function buttons do not operate.

- Error symbol on the display.

Note: If press RESET button, the unit can't work yet, please use a cotton swab soaked in isopropyl alcohol to clean the socket on the back of the front panel.


## BASIC OPERATION

---


### RADIO OPERATION

#### BAND [BAND BUTTON] (4)


In RADIO mode, press the **BAND** button on the front panel or on the remote controller to select your desired radio band and word which band is selected will be displayed on LCD. Press it to change the bands as below:



For 3 Bands (Europe)



For 2 Bands (Europe)



For 2 Bands (USA)

#### PRESET STATION [preset buttons 1-6] (7-12)

- A. To memorize the current frequency, press any one of the six preset buttons [1-6] on the front panel or on the remote controller hold for more than 2 seconds.
- B. To recall the preset memory, press one of the preset buttons [1-6].

#### AS/PS BUTTON (6)

When shortly pressing the APS button on the front panel or the A/P button on the remote controller, the radio searches for each preset station. When the field strength level is more than the threshold level of stop level, the radio is holding at that preset number for few seconds with releasing mute, and then searches again. In FM band, FM 1, FM 2 and FM 3 is checked one at a time. When long pressing the APS or A/P button (more than 1 second), the radio searches from the current frequency and checks the signal strength level until 1 cycle search is finished. And then 6 strongest stations are preset to the corresponding preset number. The AS operation is implemented in the each band of selected band. When the AS operation is finished, the radio executes the preset scan.

#### STEREO/MONO

Press the ST/MO button on the remote controller to select STEREO or MONO sound mode.

#### TUNE/SEEK UP/DOWN

Press UP or DN button on the remote controller or **▼/▲** on the front panel to manually tune up or down for your desired station. Press them hold for more than 2 seconds to automatically tune up or down for the stronger station.

#### LOC (LO/DX)

Press LO/DX button on the remote controller for distance reception when you are located at weak signal location. Depress it for stronger signal.

## BASIC OPERATION

### DISC OPERATION

Most of the disc operations are controlled by the remote controller.

#### Ejecting a Disc [▲ button]

Press (EJECT) ▲ button to eject the disc.


#### Stopping Play

Brief press the ■ (Stop) button to stop the unit playback, when press the ►► button, it can continuous normal playback.


#### Rapid Forward/Rapid Reverse

When long pressing the ►► / ◀◀ button or ▼ / ▲ button (more than 2 seconds) during play, the speed of rapid forward/reverse changes according to the disc as follow.

DVD:



VCD/CD:



MP3:



#### Skipping Track [►► / ◀◀]

Short press the ►► / ◀◀ button or ▼ / ▲ button during playback to skip to next track or back one track.

Note: For some VCD2.0 discs (PBC-playback control), ◀◀ and ►► may be unavailable.

#### Pause (still picture) (16)


Pressing ►► during playback will stop play temporary. Return to normal playback, press ►► once again.

#### Repeat [2/RPT] (8)

Press the REPEAT button to select repeat mode as follow.


DVD:

Press the REPEAT button to select repeat mode as follow.



VCD/CD:

Press the REPEAT button to select repeat mode as follow.



1. Continuously repeat at the current chapter/track, when selected REP-ONE mode.
2. Select REP-ALL mode to continuously repeat all chapter/track on the current disc.
3. REPEAT feature does not support VCD2.0 (with PBC ON).

#### Remote Sensor (IR)

Point the remote handset to the remote sensor. Receive the signal from remote handset.

### TO SELECT THE FIRST TRACK/CHAPTER TO PLAY [1/TOP BUTTON] (7)

1. In the state of VCD/CD/MP3 disc playing, press the button on the front panel to select the first track/chapter to play. (depend on the disc used for VCD)
2. In the state of DVD disc playing, the 1TOP button is not available.

### TO SCAN DISC [3/INT BUTTON](9)

1. In the state of VCD/CD disc playing, press the 3/INT button on the front panel to play the previous 10 seconds part of each track/chapter on disc. (depend on the disc used for VCD)
2. In the state of DVD/MP3 disc playing, the 3/INT button is not available.


### TO PLAY DISC IN RANDOM [4/RDM] (10)

1. In the state of VCD/CD/MP3 disc playing, press the 4/RDM button on the front panel to play in random or select DISC REP. (depend on the disc used for VCD)
2. In the state of DVD disc playing, the 4/RDM button is not available.

## BASIC OPERATION

### MP3 Disc Play

MP3 disc is playing as the format of FOLDER by FOLDER.  
For example:



Use  $\Delta$  /  $\nabla$ ,  $\blacktriangleright$  /  $\blacktriangleleft$  to select the item or folder, then press **ENTER** button.

Pressing **REPEAT** button repeatedly can select three kinds of repeat play mode.

#### REP-ONE:

Play the same song over and over again.

#### FOLDER REPEAT:

Play all songs in the current directory in sequence, over and over again.

#### DISC REPEAT:

Play all songs in the disc over and over again.

In the playback, use  $\blacktriangleleft\blacktriangleleft$  or  $\blacktriangleright\blacktriangleright$  to skip an item ahead or back.

When long pressing the  $\blacktriangleright\blacktriangleright\blacktriangleright$  /  $\blacktriangleleft\blacktriangleleft\blacktriangleleft$  to fast rapid forward/reverse.

Note: The FOLDER cannot be selected during playing. It can be selected after  $\blacksquare$  (Stop) button pressed.

### On-Screen Display Function

Press the **OSD** button during playback to display the contents of the current disc on the screen.

Example:

DVD:

(1) Press **OSD** for the first time:

TITLE 01/03 CHAPTER 002/025  
P:00:00:25 TITLE ELAPSED

Title Number, Total Title Number, Chapter Number, Total Chapter Number of this Title of the disc currently being played will be shown on the screen, along with the elapsed time.

(2) Press **OSD** for the second time:

TITLE 01/03 CHAPTER 002/025  
P: 00:00:25 TITLE REMAIN

(3) Press **OSD** for the third time:

TITLE 01/03 CHAPTER 002/025  
P:00:00:25 CHAPTER ELAPSED

(4) Press **OSD** for the fourth time:

TITLE 01/03 CHAPTER 002/025  
P: 00:00:25 CHAPTER REMAIN

(5) Press **OSD** for the fifth time:

The message on the screen will be cleared.

#### Video CD/SVCD/CD:

(1) Press **OSD** for the first time:

T:01/18 P: 00:00:25 LR DISC  
SINGLE ELAPSED

(2) Press **OSD** for the second time:

T:01/18 P: 00:00:25 LR DISC  
SINGLE REMAIN

## BASIC OPERATION

(3) Press **OSD** for the third time:

T:01/18 P: 00:00:25 LR DISC  
TOTAL ELAPSED

(4) Press **OSD** for the fourth time:

T:01/18 P: 00:00:25 LR DISC  
TOTAL REMAIN

(5) Press **OSD** for the fifth time:

The message on the screen will be cleared.  
for SVCD and VCD.

Note: For CD and Mp3, the message  
will always display on the screen.

MP3:

Each time **OSD** is pressed, the  
message displayed on screen  
changes as follows:

SINGLE ELAPSED → SIGGLE REMAIN


### Multi-audio Language Function

**DVD:**

Press **AUDIO** during playback.

Each time the button is pressed, number  
of the audio soundtrack language  
changes on sequential order.

Notes:

- The language number is different according to the disc.
- Some disc only contain one language soundtrack.
- When no different language soundtrack are recorded,  will be displayed at screen left top corner.

**VCD:**

Press **AUDIO** during playback. It is  
possible to switch the sound  
between monaural and stereo  
sound.

LEFT VOCAL → RIGHT VOCAL → MONO LEFT  
← STEREO ← MONO RIGHT ←

**CD:**

Press **AUDIO** during playback. It is  
possible to switch the sound  
between monaural and stereo  
sound.

MONO LEFT → MONO RIGHT → STEREO  
←

### TITLE Menu Function

**DVD:**

If the DVD has multiple titles  
recorded on the disc. It can select  
preferred title from the title menu to  
start playback.

1. Press **TITLE** during playback. The  
title menu is display.
2. Press the cursor button shown in  
TV screen, select preferred title by  
the cursor button and confirmed  
by **ENTER** key.

**VCD:**

Press **MENU** button while the disc is  
playing, you can switch between "BC  
on" and "PBC off" mode.


### Multi-subtitle Language Function

(For DVD only)

Press **SUBTITLE** during playback.

Each time the button is pressed,  
number of the subtitle language  
changes in sequential order.

Notes:


- The language number is different according to the disc.
- Some discs only contain one subtitle language.
- When no different subtitle language are recorded,  will be displayed at screen left top corner.

### Multi-angle Function

(For DVD only)

Press **ANGLE** during playback. Each  
time the button is pressed, number  
of the angle changes in sequential  
order.

Notes:

- The angle number is different according to the disc.
- The function only work for discs having scenes recorded at different angles.
- When no different angle are recorded,  will be displayed at screen left top corner.



# SETUP

## INITIAL SETUP

SETUP MENU --- MAIN PAGE

GENERAL SETUP

SPEAKER SETUP

AUDIO SETUP

PREFERENCES

EXIT SETUP

1. Press **SETUP** in the stop mode.  
(Press the stop button twice to ensure the player under STOP mode.)
2. The initial SETUP menu is displayed.
3. Select the preferred item by using the  $\Delta$  /  $\nabla$  buttons.
4. Press ENTER buttons.
  - a. **GENERAL SETUP**  
This setup page includes all the item of TV display & audio output feature. The detail please refer to **GENERAL SETUP MENU**.
  - b. **SPEAKER SETUP**  
This is to activate the audio output from DOLBY AC3 5.1 DOWNMIX to 2 channel mode. Please refer to **SPEAKER SETUP MENU**.
  - c. **AUDIO SETUP**  
This setup page includes all the items for AUDIO. Please refer to **AUDIO SETUP MENU**.
  - d. **PREFERENCE SETUP**  
This setup page includes all the configuration of support feature. The detail please refer to **PREFERENCES SETUP MENU**.

## GENERAL SETUP

--- GENERAL PAGE ---

TV DISPLAY

PIC MODE

ANGLE MARK

OSD LANG

CAPTIONS

SCR SAVER

NORMAL/PS

NORMAL/LB

WIDE

MAIN PAGE

Video Material	TV Screen			
	4:3			Wide (16:9)
	Normal	Pan Scan	Letter-box	
4:3				
16:9				

### TV display setup

This is to select the appropriate TV aspect (4:3 or 16:9) according to the connected TV set.

#### Normal/PS (For 4:3 TV)

Played back in the PAN & SCAN style.  
(If connected to wide-screen TV, the left and right edges are cut off.)

#### Normal/LB (For 4:3 TV)

Played back in letterbox style.  
(If connected to wide-screen TV, black bands appear at top and bottom of the screen.)

#### Wide (For 16:9 TV)

Select when a wide-screen TV set is connected.

## SETUP

--- GENERAL PAGE ---

TV DISPLAY	
PIC MODE	AUTO
ANGLE MARK	HI-RES
OSD LANG	N-FLICKER
CAPTIONS	
SCR SAVER	
MAIN PAGE	

### PIC mode setup

Select AUTO, the player PIC mode will depend on DVD disc.

Select HI-RES format for best image resolution.

Select N-FLICKER format on format on image or picture under noise affect.

--- GENERAL PAGE ---

TV DISPLAY	
PIC MODE	
ANGLE MARK	
OSD LANG	ENGLISH
CAPTIONS	
SCR SAVER	
MAIN PAGE	


### OSD LANG type setup

Select the preferred OSD language by using the ▲ / ▼ buttons.

--- GENERAL PAGE ---

TV DISPLAY	
PIC MODE	
ANGLE MARK	ON
OSD LANG	OFF
CAPTIONS	
SCR SAVER	
MAIN PAGE	

### ANGLE MARK display setup

If it is set to ON, when the multi-angle DVD disc is playing,  (the angle mark) will appear on the screen; if it is set to OFF, the mark will not appear.

--- GENERAL PAGE ---

TV DISPLAY	
PIC MODE	
ANGLE MARK	
OSD LANG	
CAPTIONS	ON
SCR SAVER	OFF
MAIN PAGE	

### CAPTIONS setup

Activate the CAPTIONS feature by selecting ON. And release this feature by selecting OFF.

# SETUP

--- GENERAL PAGE ---

TV DISPLAY	
PIC MODE	
ANGLE MARK	
OSD LANG	
CAPTIONS	
SCR SAVER	ON
	OFF
MAIN PAGE	

## SCR SAVER setup

Select the SCR SAVER output ON/OFF.

## SPEAKER SETUP

--- SPEAKER SETUP PAGE ---

DOWNMIX	LT/RT
	STEREO
MAIN PAGE	

This is to activate the audio output from DOLBY AC3 5.1 DOWNMIX to 2 channel mode. Select the preferred SPEAKER connection by using the cursor buttons.

- Select the LT/RT to activate the Dolby surround compatible output.
- Select the STEREO to activate simple stereo mode.

## AUDIO SETUP

--- AUDIO SETUP ---

AUDIO OUT	ANALOG
OP MODE	SPDIF/RAW
LPCM OUTPUT	SPDIF/PCM
DYNAMIC	
MAIN PAGE	

## AUDIO OUT

This is to activate the audio output from ANALOG mode to SPDIF/RAW mode to SPDIF/PCM mode.

--- AUDIO SETUP ---

AUDIO OUT	LINE OUT
OP MODE	RF REMOD
LPCM OUTPUT	
DYNAMIC	
MAIN PAGE	

## OP MODE

There are two operating modes for the Dolby Digital decoder: LINE OUT and RF REMOD.

# SETUP

## --- AUDIO SETUP ---

AUDIO OUT	
OP MODE	
LPCM OUTPUT	
DYNAMIC	LPCM 48K
	LPCM 96K
MAIN PAGE	

### LPCM OUTPUT

Select the LPCM OUTPUT between LPCM 48K and LPCM 96K.

## --- AUDIO SETUP ---

AUDIO OUT	
OP MODE	
LPCM OUTPUT	
DYNAMIC	FULL
	6/8
	4/8
	2/8
	OFF
MAIN PAGE	

### Dynamic Range Control

Select DRC and adjust the dynamic range of a Dolby Digital encoded program. There are 8 steps between full compression and off compression.

## PREFERENCES SETUP

### --- PREFERENCES PAGE ---

TV TYPE	MULTI
AUDIO	NTSC
SUBTITLE	PAL
DISC MENU	
PARENTAL	
PASSWORD	
DEFAULTS	
SMART NAV	
MAIN PAGE	

### TV type setup

This player can play discs recorded in either PAL or NTSC format.

Select NTSC format, when you connected to NTSC TV.

Select PAL format, when you connected to PAL TV.

Select AUTO format, the player TV output format will according to the DVD disc format.

### --- PREFERENCES PAGE ---

TV TYPE	
AUDIO	ENGLISH
SUBTITLE	FRENCH
DISC MENU	SPANISH
PARENTAL	CHINESE
PASSWORD	JAPANESE
DEFAULTS	
SMART NAV	
MAIN PAGE	

### AUDIO language setup

Select the preferred AUDIO soundtrack by using the cursor buttons.

# SETUP

## --- PREFERENCES PAGE ---

TV TYPE	
AUDIO	
SUBTITLE	ENGLISH
DISC MENU	FRENCH
PARENTAL	SPANISH
PASSWORD	CHINESE
DEFAULTS	JAPANESE
SMART NAV	OFF
MAIN PAGE	

## --- PREFERENCES PAGE ---

TV TYPE	1 G
AUDIO	2
SUBTITLE	3 PG
DISC MENU	4 PG 13
PARENTAL	5
PASSWORD	6 PG-R
DEFAULTS	7 NC-17
SMART NAV	8 ADULT
MAIN PAGE	NO_PARENTAL

### SUBTITLE language setup

Select the preferred SUBTITLE language by using the cursor buttons.

### PARENTAL

Select suitable parental guidance by the cursor buttons and confirmed by pressing ENTER button.

## --- PREFERENCES PAGE ---

TV TYPE	
AUDIO	
SUBTITLE	
DISC MENU	ENGLISH
PARENTAL	FRENCH
PASSWORD	SPANISH
DEFAULTS	CHINESE
SMART NAV	JAPANESE
MAIN PAGE	

## --- PREFERENCES PAGE ---

TV TYPE	
AUDIO	
SUBTITLE	
DISC MENU	
PARENTAL	
PASSWORD	CHANGE
DEFAULTS	
SMART NAV	
MAIN PAGE	

### DISC MENU language setup

Select the preferred DISC MENU language by using the cursor buttons.

### PASSWORD

Select the change and press ENTER button. Type the old password (The initial factory code is **3308**) and key in 4 characters password now you want to use, and retype again to confirm key in correctly.

# SETUP

## --- PREFERENCES PAGE ---

TV TYPE

AUDIO

SUBTITLE

DISC MENU

PARENTAL

PASSWORD

DEFAULTS

SMART NAV

MAIN PAGE

RESET

### DEFAULTS

Select reset to become factory initial setting.

## --- PREFERENCES PAGE ---

TV TYPE

AUDIO

SUBTITLE

DISC MENU

PARENTAL

PASSWORD

DEFAULTS

SMART NAV

MAIN PAGE

NO MENU

WITH MENU

### SMART NAV

In this item, you can select NO MENU mode or WITH MENU mode.

## DEFAULTS TABLE

General Setup	TV Display	Normal/PS
	PIC Mode	AUTO
	Angle Mark	ON
	OSD Language	English
	Captions	OFF
	SCR Saver	OFF
Speaker Setup	Downmix	Stereo
Audio Setup	Audio Out	Analog
	OP Mode	Line Out
	Dynamic	
	LPCM Out	LPCM 96K
Preferences	TV Type	MULTI
	Audio	English
	Subtitle	English
	DISC Menu	English
	Parental	NO PARENTAL
	Password	3308
	Smart Nav	With Menu

# SPECIFICATIONS

Supply voltage	: 13.8V DC (11V-15V)		
Current consumption	: Less than 10A		
Signal system	: Composite video 1.0Vp-p 75Ω		
Discs played	: (1) DVD-VIDEO disc 5"(12 cm) single-sided, single-layer 5"(12 cm) single-sided, double-layer (2) Compact disc (CD-DA, VIEDO CD) 5"(12 cm) disc		
Audio Signal Output	: 2ch & 4ch line out		
Characteristics	: (1) Frequency Response: 20 Hz-20 kHz (2) S/N Ratio: 90 dB (JIS) (3) Wow and Flutter: Below measurable limits		
	For 3 Bands (Europe) <b>FM</b>	For 2 Bands (Europe) <b>FM</b>	For 2 Bands (U.S.A.) <b>FM</b>
Frequency Coverage	: 87.5 to 108 MHz	87.5 to 108 MHz	87.5 to 107.9 MHz
IF	: 10.7 MHz	10.7 MHz	10.7 MHz
Sensitivity (S/N = 30 dB)	: 15 dBu	15 dBu	15 dBu
	<b>MW</b>	<b>MW</b>	<b>AM</b>
Frequency Coverage	: 522 to 1620 KHz	522 to 1620 KHz	530 to 1710 KHz
IF	: 450 KHz	450 KHz	450 KHz
Sensitivity (S/N = 20 dB)	: 40 dBu	40 dBu	40 dBu
	<b>LW</b>		
Frequency Coverage	: 144 to 290 KHz		
IF	: 450 KHz		
Sensitivity (S/N = 20 dB)	: 45 dBu		

**Note:**  
 Specifications and design are subject to modification, without notice, due to improvements in technology.

## TROUBLE SHOOTING

Before going through the check list, check wiring connection. If any of the problems persist after check list has been made, consult your nearest service dealer.

Symptom	Cause	Solution
No power.	The car ignition switch is not on.	If the power supply is properly connected to the car accessory terminal, switch the ignition key to "ACC".
	The fuse is blown.	Replace the fuse.
Disc cannot be loaded or ejected.	Presence of disc inside the player	Remove the disc in the player, Then put a new one
	Inserting the disc in reverse direction.	Insert the compact disc with the label facing upward.
	The disc is extremely dirty or defective	Clean the disc or try to play a new one.
	Temperature inside the car is too high.	Cool off or until the ambient temperature return to normal.
	Condensation.	Leave the player off for an hour then try again.
No sound.	Volume is in minimum.	Adjust volume to a desired level.
	Wiring is not properly connected.	Check wiring connection.
Sound skips.	The installation angle is more than 30 degrees.	Adjust the installation angle less than 30 degrees.
	The disc is extremely dirty or defective disc.	Clean the compact disc, then try to play a new one.
The operation keys do not work.	The built-in microcomputer is not operating properly due to noise.	Press the RESET button. Front panel is not properly fixed into its place.
The radio does not work.	The antenna cable is not connected.	Insert the antenna cable firmly.
	The signals are too weak.	Select a station manually.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.